CellNode BRAP



Wireless Outdoor Bridge

Product Overview

CellNode BRAP is an outdoor wireless bridge that allows multiple clients to connect to local or remote access points using 802.11b/g/n 300Mbps wireless links. The device can function in three modes: Bridge, Relay, and Access Point. In Bridge and Relay modes, CellNode BRAP extends the coverage of traditional access points by connecting multiple access points to a single fixed line (Bridge mode) or by connecting multiple access points to a remote access point (Relay mode). Additionally, CellNode BRAP can function as a traditional access point, providing network access to wireless clients. The device has an integrated 15db directional antenna that allows it to enhance its transmission range. CellNode BRA is designed for outdoors installations and has a built in Power-over-Ethernet (PoE) connection that allows the device to be installed outdoors up to 210 feet (70 meters) away from the client computer or network switch without impact on performance.



Key Features

- Multiple operating modes to accommodate different network environments
- High data exchange rate of up to 54Mbps
- Secure communication based on 64/128-bit WEP, WPA, WPA2 standards
- Auto rate fallback for improved connectivity in the presence of obstacles or interferences
- User friendly configuration via a web browser
- Extended product life via firmware upgradeability
- Controlled network access via MAC access control,
- Enhanced transmission range due to integrated directional antenna
- Remote installation of up to 210 feet from a network switch supported by PoE technology

Operating Modes

Bridge Mode

points to a wired LAN.

signals coming from its Ethernet port to its wireless port and vice versa. This functionality will allow connectivity between LAN and wireless networks. In that mode, CellNode BRAP can be used to connect multiple access

In Bridge mode, CellNode BRAP will relay all

Relay Mode

In Relay mode, CellNode BRAP extends the range of wireless networks. The device uses Wireless Distribution System (WDS) technology, allowing it to communicate directly with other access points. This way, a number of secondary access points can connect to a master access point via CellNode BRAP via wireless links.

Access Mode

CellNode BRAP can also function as a traditional access point to provide wireless clients with access to wired networks.

CellNode BRAP



Technical Specifications

• Standards: IEEE 802.11g (DSSS) 2.4GHz specification

Operating Frequency:

2.400 GHz to 2.4835 GHz frequency band

1~14 channels

• Data rate: Up to 300Mbps

Operating Modes:

Access Point

Access Point Client

Bridge Point-to-Point

Bridge Point-to-Multipoint

WDS

Repeater

Security: 64/128-bit WEP, WPA, WPA2

CPU: Realtek RTL8186Flash: 2 MB NOR Flash

• RAM: 8MB SDRAM

• RF: Realtek RTL8225

• Interface: RJ-45 10/100Mbps Port

Misc:

Power over Ethernet Injector CAT5/FTP Ethernet Cable (3.5m)

Antenna: Integrated 15db 2.4Ghz

• Transmit Power: 18 dBm

• Certifications: FCC, CE

Configuration: Web browser


• Upgradeability: Firmware

• Power: 12V DC, 0.5A

Dimensions (H x W x D): 50 mm x 210 mm x 210 mm

• Operating Temperature: -4F to 122F (-20C to 50C)

Operating Humidity: 10% to 90% Non-Condensing





SysMaster 2700 Ygnacio Valley Rd, Suite 210 Walnut Creek, CA 94598 United States of America

Email: sales@sysmaster.com Web site: www.sysmaster.com

Notice to Recipient: All information contained herein and all referenced documents (the "Documents") are provided subject to the Terms of Service Agreement (the "Terms") found on SysMaster Corporation's ("SysMaster") website, http://www.sysmaster.com (the "Site"), which location and content of Terms may be amended from time to time, except that for purposes of this Notice, any reference to Content on the Site shall also incorporate and include the Documents. This document does not create any express or implied warranty by SysMaster, and all information included in the Documents is provided for informational purposes only and SysMaster provides no assurances or guarantees as to the accuracy of such information and shall not be liable for any errors or omissions contained in the Documents, beyond that provided for under the Terms. SysMaster's sole warranty is contained in the written product warranty for each product. The end-user documentation shipped with SysMaster provides constitutes the sole specifications referred to in the product warranty. The Recipient is solely responsible for verifying the suitability of SysMaster's products for its own use. Specifications are subject to change without notice.